

1	105.32.0.1	Tappet - spring
2	105.32.11.1	Pneumatic - spring
3	105.32.11.11	Pneumatic - Pneumatic
4	105.32.11.12	Pneumatic - diff/al
5	105.32.2.1	Lever roller
6	105.32.2.1/1	Lever roller ball bearing - spring
7	105.32.2.6/1	Lever red button- spring
8	105.32.2.6/2	Lever black button- spring
9	105.32.2.6/3	Lever green button- spring
10	105.32.3.1	Lever roller unidir. - spring
11	105.32.4/1	Lever pann. Ø22 red
12	105.32.4/2	Lever pann. Ø22 black
13	105.32.4/3	Lever pann. Ø22 green
14	105.32.5/1	Lever pann. Ø30 red
15	105.32.5/2	Lever pann. Ø30 black
16	105.32.5/3	Lever pann. Ø30 green
17	105.32.6.1/1	Push button Ø30 red - spring
18	105.32.6.1/2	Push button Ø30 black - spring
19	105.32.6.1/3	Push button Ø30 green - spring
20	105.32.6.2/1	Push button Ø22 red - spring
21	105.32.6.2/2	Push button Ø22 black - spring
22	105.32.6.2/3	Push button Ø22 green - spring
23	105.32.6.22/1	Push button red - spring
24	105.32.6.22/2	Push button black - spring
25	105.32.6.22/3	Push button green - spring
26	105.32.6.22/4	Push button yellow - spring
27	105.32.6.23/1	Raised Push button red - spring
28	105.32.6.23/2	Raised Push button black - spring
29	105.32.6.23/3	Raised Push button green - spring
30	105.32.6.23/4	Raised Push button yellow - spring
31	105.32.6.27	Switch
32	105.32.6.28	Key Switch
33	105.32.6.40A	Handle N.O.
34	105.32.6.40C	Handle N.C.
35	105.32.7.1/1	Palm push button Ø30 red - spring
36	105.32.7.1/2	Palm push button Ø30 black - spring
37	105.32.7.1/3	Palm push button Ø30 green - spring
38	105.32.7.2/1	Palm push button Ø22 red - spring
39	105.32.7.2/2	Palm push button Ø22 black -spring
40	105.32.7.2/3	Palm push button Ø22 green - spring
41	105.32.8.1/1	Push button red - spring
42	105.32.8.1/2	Push button black - spring
43	105.32.8.1/3	Push button green - spring
44	105.32.8/1	Push button red
45	105.32.8/2	Push button black
46	105.32.8/3	Push button green
47	105.32.9.1	Whisker - spring
48		
49	105.52.0.1	Tappet - spring
50	105.52.11.1	Pneumatic - spring
51	105.52.11.11	Pneumatic - Pneumatic
52	105.52.11.12	Pneumatic - diff/al
53	105.52.2.1	Lever roller - spring
54	105.52.2.1/1	Lever roller ball bearing - spring
55	105.52.2.6/1	Lever red button- spring
56	105.52.2.6/2	Lever black button- spring
57	105.52.2.6/3	Lever green button- spring
58	105.52.3.1	Lever roller unidir. - spring
59	105.52.4/1	Lever pann. Ø22 red
60	105.52.4/2	Lever pann. Ø22 black
61	105.52.4/3	Lever pann. Ø22 green
62	105.52.5/1	Lever pann. Ø30 red
63	105.52.5/2	Lever pann. Ø30 black
64	105.52.5/3	Lever pann. Ø30 green
65	105.52.6.1/1	Push button Ø30 red - spring
66	105.52.6.1/2	Push button Ø30 black - spring
67	105.52.6.1/3	Push button Ø30 green - spring
68	105.52.6.2/1	Push button Ø22 red - spring

69	105.52.6.2/2	Push button Ø22 black - spring
70	105.52.6.2/3	Push button Ø22 green - spring
71	105.52.6.22/1	Push button red - spring
72	105.52.6.22/2	Push button black - spring
73	105.52.6.22/3	Push button green - spring
74	105.52.6.22/4	Push button yellow - spring
75	105.52.6.23/1	Raised Push button red - spring
76	105.52.6.23/2	Raised Push button black - spring
77	105.52.6.23/3	Raised Push button green - spring
78	105.52.6.23/4	Raised Push button yellow - spring
79	105.52.6.27	Switch
80	105.52.6.28	Key Switch
81	105.52.6.40	Handle "left"
82	105.52.6.40D	Handle "right"
83	105.52.7.1/1	Palm push button Ø30 red - spring
84	105.52.7.1/2	Palm push button Ø30 black - spring
85	105.52.7.1/3	Palm push button Ø30 green - spring
86	105.52.7.2/1	Palm push button Ø22 red - spring
87	105.52.7.2/2	Palm push button Ø22 black - spring
88	105.52.7.2/3	Palm push button Ø22 green - spring
89	105.52.8.1/1	Push button red - spring
90	105.52.8.1/2	Push button black - spring
91	105.52.8.1/3	Push button green - spring
92	105.52.8/1	Push button red
93	105.52.8/2	Push button black
94	105.52.8/3	Push button green
95	105.52.9.1	Whisker - spring
96		
97	105.53.32.99/1	Lever centr. red - spring
98	105.53.32.99/2	Lever centr. black - spring